(CCD FLEX.CARD C.B.A.)

:VIDEO MAIN SIGNAL PATH

IC203
C4AZJ0000003:VV-GS200SERIES
MN39236:NV-GS120SERIES
(CCD,B)

IC202
C4AZJ0000003:VV-GS200SERIES
MN39236:NV-GS120SERIES
(CCD,R)

IC201
C4AZJ0000003:VV-GS200SERIES
MN39236:NV-GS120SERIES
(CCD,G)

Q203 2SC4627JCL (AMP)
Q202 2SC4627JCL (AMP)
Q201 2SC4627JCL (AMP)
Q204 2SC4627JCL (FILTER)
Q205 2SC4627JCL (FILTER)
Q206 2SC4627JCL (FILTER)

(NV-GS200SERIES ONLY)
(NV-GS120SERIES ONLY)
(NV-GS120 SERIES ONLY)
(NV-GS200 SERIES ONLY)

TO SUB CONNECTION PP201

40	A GND
39	H2 B
38	H1 B
37	SUB B
36	V2 B
35	V4 B
34	R
33	H2 G
32	H1 G
31	SUB G
30	-8V
29	-8V
28	V1 R
27	V2 R
26	V3 R
25	V4 R
24	H2 R
23	H1 R
22	SUB R
21	A GND
20	SIG R
19	A GND
18	5V RG
17	5V RG
16	A GND
15	A GND
14	SIG G
13	A GND
12	V1 G
11	V2 G
10	V3 G
9	V4 G
8	15V
7	15V
6	V3 B
5	V1 B
4	5V B
3	5V B
2	A GND
1	SIG B

TO PS201

NOTE:
DO NOT USE ANY PART NUMBER SHOWN ON THIS SCHEMATIC DIAGRAM FOR ORDERING.WHEN YOU ORDER A PART,PLEASE REFER TO PARTS LIST.

NOTE:
THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.

NV-GS200SERIES,GS120SERIES
CCD FLEX. CARD
SCHEMATIC DIAGRAM